

IkeaDocuScan V3 - Deployment Checklist

Quick Reference Guide for IKEA Deployment

Framework: .NET 10.0 **Organization:** IKEA (ikea.com)

Print this checklist and check off items as you complete them during deployment.

Pre-Deployment (Day Before)

- ☐ Backup production database
 - ☐ Backup current appsettings.Local.json
 - ☐ Backup current secrets.encrypted.json
 - ☐ Document current version: _____
 - ☐ Verify .NET 10.0 Runtime installed on server
 - ☐ Verify ASP.NET Core Hosting Bundle 10.0 installed
 - ☐ Schedule maintenance window
 - ☐ Notify users of deployment
-

Version Management

- ☐ Open IkeaDocuScan-Web.csproj
 - ☐ Update <VersionPrefix> to: _____
 - ☐ Update <VersionSuffix> to: _____
 - ☐ Save file
 - ☐ Rebuild solution successfully
-

Publishing

- ☐ Clean solution
 - ☐ Rebuild solution (no errors)
 - ☐ Right-click IkeaDocuScan-Web → Publish
 - ☐ Select/Create publish profile
 - ☐ Verify settings: Release, net10.0, Framework-dependent
 - ☐ Click Publish
 - ☐ Verify publish succeeded
 - ☐ Note publish path: _____
 - ☐ Copy DbMigration-scripts to publish folder
 - ☐ Copy ConfigEncryptionTool to Tools folder
 - ☐ Create deployment ZIP file
 - ☐ Transfer ZIP to server
-

Database

- ☐ Production database backup restored
- ☐ OR new database created: IkeaDocuScan
- ☐ Migration scripts executed in order (ALL 8 scripts):
 - ☐ 00_Create_Database_And_User.sql
 - ☐ 00A_Restore_And_Migrate_Schema.sql

- ☐ 02_Migrate_FK_Data.sql
 - ☐ 03_Finalize_FK_Constraints.sql
 - ☐ 04_Create_DocuScanUser_Table.sql
 - ☐ 05_Migrate_Users_To_DocuScanUser.sql
 - ☐ 06_Add_FK_Constraint_UserPermissions.sql
 - ☐ 07_Remove_AccountName_From_UserPermissions.sql
 - ☐ Verify docuscanch login exists
 - ☐ Verify docuscanch user has database access
 - ☐ Connection tested with docuscanch user
 - ☐ Database configuration verified (TBD)
-

File Deployment

- ☐ Stop IIS Application Pool
 - ☐ Extract ZIP to: C:\inetpub\wwwroot\IkeaDocuScan
 - ☐ Verify key files present:
 - ☐ IkeaDocuScan-Web.dll
 - ☐ web.config
 - ☐ wwwroot_framework
 - ☐ DbMigration-scripts*.sql
 - ☐ Tools
 - ☐ Create logs directory
 - ☐ Set file permissions
-

IIS Configuration

Application Pool

- ☐ Create Application Pool: IkeaDocuScan
- ☐ .NET CLR version: No Managed Code
- ☐ Managed pipeline mode: Integrated
- ☐ Advanced Settings:
 - ☐ Identity: ApplicationPoolIdentity (or service account)
 - ☐ Idle Time-out: 0
 - ☐ Load User Profile: True
 - ☐ Start Mode: AlwaysRunning

Website/Application

- ☐ Create website OR application
- ☐ Bind to Application Pool: IkeaDocuScan
- ☐ Physical path: C:\inetpub\wwwroot\IkeaDocuScan
- ☐ HTTPS binding configured
- ☐ SSL certificate selected

Authentication

- ☐ Anonymous Authentication: **Disabled**
- ☐ Windows Authentication: **Enabled**
- ☐ Extended Protection: Accept
- ☐ Kernel-mode authentication: Enabled

WebSocket

- ☐ WebSocket Protocol feature installed
 - ☐ Enabled for application
-

Application Configuration

- ☐ Run ConfigEncryptionTool as App Pool identity
 - ☐ Enter SQL Server name
 - ☐ Use SQL auth: docuscanch user
 - ☐ Enter docuscanch password
 - ☐ Enter ScannedFilesPath
 - ☐ Verify encryption test succeeds
 - ☐ Copy secrets.encrypted.json to app root
 - ☐ Create appsettings.Local.json:
 - ☐ IkeaDocuScan → DomainName (ikea.com)
 - ☐ IkeaDocuScan → UserEmail LDAP settings
 - ☐ IkeaDocuScan → EmailGroups LDAP settings
 - ☐ IkeaDocuScan → IKEA AD Groups (3):
 - ☐ ADGroupReader
 - ☐ ADGroupPublisher
 - ☐ ADGroupSuperUser
 - ☐ Email → SmtpHost (smtp-gw.ikea.com)
 - ☐ Email → ApplicationUrl
 - ☐ ExcelExport → ApplicationUrl
 - ☐ Verify configuration file permissions
-

File Permissions

- ☐ Application directory: Read & Execute for App Pool
 - ☐ Logs directory: Modify for App Pool
 - ☐ Scanned files path: Read & Execute for App Pool
 - ☐ Configuration files: Read for App Pool only
 - ☐ Test file access as App Pool identity
-

Windows Authentication

- ☐ Verify IKEA AD groups exist:
 - ☐ UG-DocScanningReaders-CG@WAL-FIN-CH-GEL
 - ☐ UG-DocScanningPublishers-CG@WAL-FIN-CH-GEL
 - ☐ UG-DocScanningSuperUsers-CG@WAL-FIN-CH-GEL
 - ☐ Verify LDAP connectivity (LDAP://DC=ikea,DC=com)
 - ☐ Add initial admin user(s) to SuperUser AD group
 - ☐ Database seeding for initial admin (TBD)
-

Post-Deployment Verification

Application Status

- ☐ Application Pool started
- ☐ Check stdout logs for startup success
- ☐ Check Event Viewer for errors
- ☐ Browse to application URL successfully

Functionality Tests

- ☐ Home page loads
- ☐ Windows Authentication works automatically
- ☐ User sees correct access based on AD group
- ☐ Documents → Search works
- ☐ View document details
- ☐ Access scanned files
- ☐ Generate Excel export
- ☐ Email notifications work (if enabled)

Health Checks

- ☐ /health returns “Healthy”
- ☐ /health/ready returns JSON
- ☐ /health/live returns JSON

Version Verification

- ☐ Verify version number: _____
- ☐ Check file version of IkeaDocuScan-Web.dll

Common Issues Quick Reference

Pool Stops Immediately: - Check stdout logs - Verify .NET 10.0 Runtime: `dotnet --list-runtimes`

Database Connection Fails: - Verify secrets.encrypted.json exists - Test: `sqlcmd -S SERVER -d IkeaDocuScan -U docuscanch -P [password]` - Verify docuscanch user exists and has access - Re-run ConfigEncryptionTool if password incorrect

Windows Auth Not Working: - Disable Anonymous Authentication - Enable Windows Authentication - Check browser Intranet zone settings

Cannot Access Files: - Test as App Pool identity: `runas /user:"IIS APPPOOL\IkeaDocuScan" "cmd.exe"` - Verify network share permissions

SignalR Not Working: - Install WebSocket Protocol feature - Check ARR proxy settings

Rollback (If Needed)

- ☐ Stop Application Pool
- ☐ Restore previous files from backup
- ☐ Restore appsettings.Local.json
- ☐ Rollback database (if migrations applied)
- ☐ Start Application Pool
- ☐ Verify functionality

Sign-Off

Role	Name	Signature	Date/Time
Deployer			
Technical Lead			
QA/Tester			

Deployment Notes:

[Space for notes about any issues, deviations, or special configurations]

Next Steps

- ☐ Monitor application logs for 24 hours
- ☐ Review Performance Monitor metrics
- ☐ Schedule smoke testing (see SMOKE_TEST.md when available)
- ☐ Update documentation with any environment-specific details
- ☐ Notify users deployment is complete

Deployment Completed: _____ **Environment:** ☐ Production ☐ Staging ☐
UAT Version Deployed: _____